

SASH WINDOW PET DOOR INSTALLATION INSTRUCTIONS

1. RAISE YOUR SASH WINDOW PANE. HOLD SECURE.
2. FOAM BUMPER SEAL IS INCLUDED. CUT 2 PCS. BUMPER SEAL TO SAME LENGTH AS WIDTH OF WINDOW. PEEL OFF PROTECTIVE BACKING AND ATTACH FOAM ALONG TOP AND BOTTOM EDGE OF PET DOOR.
3. PLACE THE PET DOOR ASSEMBLY BETWEEN THE WINDOW SILL AND THE OPEN WINDOW.
4. LOWER THE WINDOW PANE UNTIL IT TOUCHES DOWN ONTO THE PET DOOR ASSEMBLY.
5. TURN THE SILVER KNOBS COUNTER-CLOCKWISE, ONE TURN, TO RELEASE THE END SPACERS.
6. PET DOOR ASSEMBLY SHOULD NOW FIT THE WINDOW SNUGLY ON BOTH ENDS.
7. TURN SILVER KNOBS CLOCKWISE TO LOCK ENDS IN POSITION.
8. VINYL DRAFT STOPPER EXTRUSION IS INCLUDED. CUT TO REQUIRED LENGTH, CLEAN WINDOW SURFACE AND PEEL OFF PROTECTIVE BACKING. ATTACH ALONG TOP EDGE OF THE LOWER WINDOW. MAKE SURE INSIDE FLEXIBLE EDGE TOUCHES GLASS

****IF KNOBS INTERFER WITH BOTTOM SILL, YOU MAY REMOVE KNOBS AS FOLLOWS:**

1. TAKE OUT 2 SCREWS THAT HOLD ADJUSTABLE END EXTRUSIONS.
2. PUSH STEEL RODS INTO LONG BOTTOM EXTRUSION ABOUT 1/8" BELOW SURFACE. LOCKING KNOB AND PIN WILL THEN PULL OUT.
3. RE-ASSEMBLE ADJUSTABLE END EXTRUSIONS.

NOTE: LEAVE TOP KNOB IN PLACE TO LOCK YOUR PET DOOR IN POSITION.

ADDITIONAL SECURITY LOCK FOR WINDOW ENCLOSED
SEE INSTRUCTIONS WITH ENCLOSED "LOCK KIT"